







































































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Mute		Mute / Dimmer
	SUBT.		Subtitle / EQ
	TV		TV/Radio /
	Tools		Setup / OPT /
	TTX/MIX		Text / Goto
	Source		AV / Input / RDS
	Menu		Menu / Home
	Up		Up
	Info		Info / Angle
	Left		Left
	Enter		OK
	Right		Right
	Exit		Exit / Cancel / Clear
	Down		Down
	PRE-CH		Back / Return
	VOL+		Vol+

Originalfernbedienung Ersatzfernbedienung

	CH.LIST		Smart / List
	PR+		CH+ / Page+
	VOL-		Vol-
	PR-		CH- / Page-
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	GUIDE		Guide / EPG / -/-
	0		0
	FAV.CH		Fav / Marker / PC
	Red		Red / Netflix / Search



