
































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Mute		Mute
	Eject		Eject
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Recall		Pre Ch
	-/--		Shift + Guide
	Vol+		Vol +
	Aspect		Format

Originalfernbedienung Ersatzfernbedienung

	Nicam		Shift + Dual
	Vol-		Vol -
	CH+		Ch +
	CH-		Ch -
	Enter		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Display		Shift + Info
	LCD Menu		Menu
	Exit/DVD Setup		Exit
	Sleep		Sleep
	Input		AV
	Red/Prog		Red
	Tv/Radio		TV/R
	Green/Intro/Audio		Green



