













Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	-/--		Shift + Guide / EPG / -/--
	0		0
	Recall		Back / Return
	Audio		Audio / Lang I/II
	FAV+		Shift + CH+ /
	FAV		Fav / Marker / PC

Originalfernbedienung Ersatzfernbedienung

	FAV-		Shift + CH- /
	CH+		CH+ / Page+
	P.Mode		Picture / Format
	Vol+		Vol+
	CH-		CH- / Page-
	S.Mode		Sound / Title
	Vol-		Vol-
	Source		AV / Input / RDS
	Sleep		Sleep / Timer
	Aspect		Shift + Picture / Format
	Info		Info / Angle
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Menu		Menu / Home
	Down		Down



