



Originalfernbedienung **Ersatzfernbedienung**

	LIGHT On/Off		Power
	Fan OFF		0
	1H		Red / Netflix / Search
	2H		Green / APP / Repeat
	4H		Yellow / YouTube / Repeat
	Fan LOW		1
	Fan MED		2
	Fan HIGH		3

Originalfernbedienung **Ersatzfernbedienung**





Originalfernbedienung Ersatzfernbedienung

	Light On/Off		Power
	Fan Off		0
	1H		Red / Netflix / Search
	2H		Green / APP / Repeat
	4H		Yellow / YouTube / Repeat
	Fan LOW		1
	Fan MED		2
	Fan HIGH		3

Originalfernbedienung Ersatzfernbedienung





Originalfernbedienung Ersatzfernbedienung


LIGHT ON/OFF	Light On/Off		Power
FAN OFF	Fan Off		0
1H	Timer 1H		Red / Netflix / Search
2H	Timer 2H		Green / APP / Repeat
4H	Timer 4H		Yellow / YouTube / Repeat
LOW	Fan Low		1
MED	Fan Med		2
HIGH	Fan High		3

Originalfernbedienung Ersatzfernbedienung





Originalfernbedienung Ersatzfernbedienung

	Light On/Off		Power
	Fan Off		0
	Timer 1H		1
	Timer 2H		2
	Timer 4H		3
	Fan LOW		Yellow / YouTube / Repeat
	Fan MED		Green / APP / Repeat
	Fan HI		Red / Netflix / Search

Originalfernbedienung Ersatzfernbedienung

