








































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	TV		TV/R
	Subtitle		Subt
	Teletex/MHEG		Text
	Source		AV
	Red/Demo		Red
	Green/Scenea		Green
	Yellow		Yellow
	Blue/AD		Blue
	Home		Smart
	Guide		Guide
	Options		Options
	Back		Back
	Info		Info
	Up		Up
	Down		Down
	Right		Right

Originalfernbedienung Ersatzfernbedienung

	Left		Left
	OK		Ok
	<<		<<
	Play		Play
	Pause		Pause
	>>		>>
	Stop		Stop
	Rec		Rec
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Format		Format
	P+		Ch +
	P-		Ch -
	1		1
	2		2
	3		3



