









































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Open/Close		Eject
	Mode/HDMI		Shift + AV
	Reso/Resolution		Shift + TV/R
	Home		Smart
	Pure/Pure Direct		Shift + Subt
	Mode/Sound		Sleep
	P/D/Prog Direct		Shift + Options
	ADJ./Pict.		Shift + Format
	CLR/Clear		Exit
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7

Originalfernbedienung Ersatzfernbedienung



































	8		8
	9		9
	0		0
	+10		Guide
	Call		Pre Ch
	Input Up		Ch +
	Input Down		Ch -
	Power Amp		Shift + Power
	Mute		Mute
	Vol+		Vol +
	Vol-		Vol -
	Top Menu		Menu
	Pop Up Menu		Media
	Up		Up
	Left		Left
	Enter		Ok
	Right		Right











**Originalfernbedienung   Ersatzfernbedienung**

	Power		Power
	Open/Close		Eject
	Mode/HDMI		Shift + AV
	Reso/Resolution		Shift + TV/R
	Home		Smart
	Pure/Pure Direct		Shift + Subt
	Mode/Sound		Sleep
	P/D/Prog Direct		Shift + Options
	ADJ./Pict.		Shift + Format
	CLR/Clear		Exit
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7

**Originalfernbedienung   Ersatzfernbedienung**

	8		8
	9		9
	0		0
	+10		Guide
	Call		Pre Ch
	Input Up		Ch +
	Input Down		Ch -
	Power Amp		Shift + Power
	Mute		Mute
	Vol+		Vol +
	Vol-		Vol -
	Top Menu		Menu
	Pop-Up Menu		Media
	Up		Up
	Left		Left
	Enter		Ok
	Right		Right



