





































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Eject		Eject
	Tv/VCR		TV/R
	AV		AV
	CM Skip		Options
	ez Power Off		Smart
	ez Repeat		Text
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0

Originalfernbedienung Ersatzfernbedienung

	<<		<<
	Play		Play
	>>		>>
	Pause/Still		Pause
	Stop		Stop
	LP		Media
	C.Lock		Back
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	i		Info
	OK/CLK/CNT		Ok
	Clear		Exit
	Rec/OTR		Rec

