

























































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--		Shift + Guide
	Recall		Pre Ch
	Info		Info
	EPG		Guide
	Source		AV

Originalfernbedienung Ersatzfernbedienung

	Vol+		Vol +
	Vol-		Vol -
	Prog+		Ch +
	Prog-		Ch -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Sleep		Sleep
	Menu		Menu
	FAV		Shift + Pre Ch
	Format		Format
	Text		Text
	Subtitle		Subt
	Red/Size		Red
	Green/Reveal		Green



