







































































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Quick Select 1		1
	Quick Select 2		2
	Quick Select 3		3
	Quick Select 4		4
	CBL/SAT		5
	DVD		6
	Blu-ray		7
	Game		8
	AUX		9
	Tv Audio		Guide
	Tuner		0
	Memory		Pre Ch
	Band		List
	Shift		AV
	Mode		Exit
	Channel +		Ch +

Originalfernbedienung Ersatzfernbedienung

	Channel -		Ch -
	Tune +		>>
	Tune -		<<
	Mute		Mute
	CH Level		3D
	Sleep		Sleep
	Dimmer		Text
	Search		TV/R
	Info		Info
	Audio		Dual
	Back		Back
	Setup		Menu
	Vol+		Vol +
	Vol-		Vol -
	Up		Up
	Down		Down
	Right		Right



