









































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Sleep		Sleep
	CBL/SAT		1
	DVD		2
	Blu-ray		3
	Game		4
	AUX1		5
	Media Player		6
	TV/Audio		7
	AUX2		8
	Tuner		9
	USB		Guide
	CD		0
	Bluetooth		Pre Ch
	Internet Radio		Smart
	CH/Page+		Media
	CH/Page-		Ch +

Originalfernbedienung Ersatzfernbedienung

	CH/Page-		Ch -
	Eco		3D
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Info		Info
	Option		Options
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	Back		Back
	Setup		Menu
	I<</Tune-		I<<
	Play		Play
	Pause		Pause





Originalfernbedienung Ersatzfernbedienung



































	>> /Tune+		>>
	Smart Select 1		D. Menu
	Smart Select 2		Text
	Smart Select 3		Eject
	Smart Select 4		AV
	Green/Movie		Green
	Red/Music		Red
	Blue/Game		Blue
	Yellow/Pure		Yellow

Originalfernbedienung Ersatzfernbedienung





Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Sleep		Sleep
	CBL/SAT		1
	DVD		2
	Blu-ray		3
	Game		4
	AUX1		5
	Media Player		6
	TV Audio		7
	AUX2		8
	Tuner		9
	USB		Guide
	CD		0
	Bluetooth		Pre Ch
	Internet Radio		Smart
	CH/Page+		Media
	CH/Page-		Ch +

Originalfernbedienung Ersatzfernbedienung

	CH/Page-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	Back		Back
	I<</Tune-		I<<
	Play		Play
	Pause		Pause
	>>I/Tune+		>>I
	Smart Select 1		D. Menu
	Smart Select 2		Text
	Smart Select 3		Eject



