





































































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Input		AV
	Digital/Analog		TV/R
	Sync Menu		Menu
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Exit		Exit
	[≡]		Text
	Red		Red

Originalfernbedienung Ersatzfernbedienung

	Green		Green
	Yellow		Yellow
	Blue		Blue
	YouTube		Media
	Netflix		Shift + Media
	Sleep		Sleep
	Info		Info
	Guide		Guide
	Options		Options
	Home		Smart
	Return		Back
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Ok		Ok
	Vol+		Vol +





Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
	Vol-		
	Mute		
	Recall		
	CH+		
	CH-		
	Audio		
	[...]		
	Title List		
	<<		
	Play		
	>>		
	I<<		
	Pause		
	>>I		
	Rec		
	Stop		
	[+]		

