




















































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Voyo		Smart
	Guide		Guide
	List		List
	Info		Info
	Vol+		Vol +
	Vol-		Vol -
	P+		Ch +
	P-		Ch -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Red		Red
	Green		Green
	Yellow		Yellow



































Originalfernbedienung Ersatzfernbedienung

	Blue		Blue
	Back		Back
	Exit		Exit
	Stop		Stop
	<<		<<
	Play		Play
	Pause		Pause
	>>		>>
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9



























Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Voyo		Smart
	Guide		Guide
	List		List
	Info		Info
	Vol+		Vol +
	Vol-		Vol -
	P+		Ch +
	P-		Ch -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Red		Red
	Green		Green
	Yellow		Yellow

Originalfernbedienung Ersatzfernbedienung

	Blue		Blue
	Back		Back
	Exit		Exit
	Stop		Stop
	<<		<<
	Play		Play
	Pause		Pause
	>>		>>
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9



