





































**Originalfernbedienung Ersatzfernbedienung**

	3D		Picture / Format
	Power		Power
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Prog+		CH+ / Page+
	0		0
	Vol+		Vol+
	Prog-		CH- / Page-
	Vol-		Vol-

**Originalfernbedienung Ersatzfernbedienung**

	Up/CH+		Up
	Left/Vol-		Left
	OK		OK
	Right/Vol+		Right
	Down/CH-		Down
	Menu		Menu / Home
	Exit		Exit / Cancel / Clear
	Info		Info / Angle
	EPG		Guide / EPG / -/--
	List		Smart / List
	TXT		Text / Goto
	S-T		Sound / Title
	Tv/R		TV/Radio /
	Timer		Sleep / Timer
	Audio		Audio / Lang I/II
	Play		Play / Slow
	Pause		Pause / Step / Freeze



