








































**Originalfernbedienung Ersatzfernbedienung**

	Power		Power
	Open/Close		Eject
	USB		Blue
	CD		Yellow
	Tuner		Green
	AUX		Red
	Vol-		Vol -
	Vol+		Vol +
	I<<		I<<
	>>I		>>I
	Album/Preset		Ch -
	Album/Preset		Ch +
	Stop		Stop
	Play / Pause		Play
	Play / Pause		Pause
	Program	 + 	Shift + Sleep
	Clock/Display		Info

**Originalfernbedienung Ersatzfernbedienung**

	Timer		AV
	Sleep		Sleep
	DBB		Dual
	DSC		Subt
	RDS/News		TV/R
	Mute		Mute
	Repeat		Text
	Shuffle		Format









