






































Originalfernbedienung Ersatzfernbedienung










	Power		Power
	Display	 + 	Shift + Info
	V-Mode		Format
	Open / Close		Eject
	Language		Dual
	Step	 + 	Shift + Stop
	Slow	 + 	Shift + Pause
	Repeat		Text
	Angle		TV/R
	Resume		List
	A-B	 + 	Shift + Text
	Return		Back
	Subt / CD Ripping		Subt
	DVD / USB		Media
	Time		AV
	Zoom	 + 	Shift + Eject
	Menu		Menu

Originalfernbedienung Ersatzfernbedienung

	Title		Info
	Up		Up
	Right		Right
	Down		Down
	Left		Left
	Enter		Ok
	Setup		Options
	PBC		Smart
	P / N		D. Menu
	Pause		Pause
	Play		Play
	Vol +		Vol +
	Vol -		Vol -
	Prog		Sleep
	L / R	 + 	Shift + Dual
	Stop		Stop
	1		1





	Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
	2			
	3			
	4			
	5			
	6			
	7			
	8			
	9			
	0 / 10			
	10+			
	MUTE			
	REV << Rev			
	Fwd >>			
	I<< Prev			
	Next >>I			

