







































































Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
 Standby / On	 Power	 Clear	 Exit
 Open / Close	 Eject	 Setup	 Options
 1	 1	 Title	 Info
 2	 2	 Menu	 Menu
 3	 3	 Enter	 Ok
 4	 4	 Up	 Up
 5	 5	 Right	 Right
 6	 6	 Down	 Down
 7	 7	 Left	 Left
 8	 8	 PBC	 Smart
 9	 9	 Play	 Play
 0	 0	 Zoom	 Shift + Eject
 10+	 Guide	 Repeat	 Text
 Goto	 Pre Ch	 Pause	 Pause
 Audio	 Dual	 A-B	 Shift + Text
 Subtitle	 Subt	 Prog	 Sleep
 Angle	 Format	 OSD	 Red



