







































































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	VOD		Media
	n		Smart
	EPG		Guide
	Home		Menu
	Info		Info
	Back		Back
	OPT		Options
	Vol+		Vol +
	Vol-		Vol -
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	CH+		Ch +
	CH-		Ch -

Originalfernbedienung Ersatzfernbedienung

	Stop		Stop
	<<		<<
	Pause		Pause
	Play		Play
	>>		>>
	R		Rec
	Mute		Mute
	@		TV/R
	Text		Text
	List		List
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	1		1
	2		2
	3		3



