











































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Vol+		Vol+
	Vol-		Vol-
	Mute		Mute / Dimmer
	Return		Back / Return
	PR+		CH+ / Page+
	>>I		>>I / Preset+
	I<<		I<< / Preset-
	PR-		CH- / Page-
	Exit		Exit / Cancel / Clear
	Menu		Menu / Home
	Up		Up
	Down		Down
	Right/Zoom+		Right
	Left/Zoom-		Left
	OK		OK
	Red		Red / Netflix / Search

Originalfernbedienung Ersatzfernbedienung

	Sound		Sound / Title
	Green		Green / APP / Repeat
	List		Shift + Smart / List
	Yellow		Yellow / YouTube / Repeat
	Info		Info / Angle
	Mosaic		Smart / List
	Blue		Blue / Prime Video / Random
	Violet		Display / Media
	Text		Text / Goto
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8






Originalfernbedienung Ersatzfernbedienung



































	9		9
	0/--		0
	AV		AV / Input / RDS
	PIP		Zoom / Size
	<</Pat-Mix		<< / Tune-
	Play/?		Play / Slow
	>>		>> / Tune+
	Rec/100		Rec / Rec Mode
	Stop		Stop / Hold
	Pause/----		Pause / Step / Freeze
	Swap PIP		Setup / OPT /
	Size PIP		Picture / Format
	Position PIP		TV/Radio /

Originalfernbedienung Ersatzfernbedienung


























Originalfernbedienung Ersatzfernbedienung



























	Power		Power
	Vol+		Vol+
	Vol-		Vol-
	Mute		Mute / Dimmer
	Return		Back / Return
	PR+		CH+ / Page+
	>>I		>>I / Preset+
	PR-		CH- / Page-
	I<<		I<< / Preset-
	Exit		Exit / Cancel / Clear
	Menu		Menu / Home
	Up		Up
	Down		Down
	Right/Zoom+		Right
	Left/Zoom-		Left
	OK		OK
	Red		Red / Netflix / Search

Originalfernbedienung Ersatzfernbedienung


	Sound		Sound / Title
	Green		Green / APP / Repeat
	List		Shift + Smart / List
	Info		Info / Angle
	Yellow		Yellow / YouTube / Repeat
	Mosaic		Smart / List
	Blue		Blue / Prime Video / Random
	Violet		Display / Media
	Text		Text / Goto
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8







































	Originalfernbedienung	Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
	9		9		
	0/-/--		0		
	AV		AV / Input / RDS		
	PIP		Zoom / Size		
	<</Pat-Mix		<< / Tune-		
	Play/?		Play / Slow		
	>>		>> / Tune+		
	Rec/100		Rec / Rec Mode		
	Stop		Stop / Hold		
	Pause/----		Pause / Step / Freeze		
	Swap PIP		Setup / OPT /		
	Size PIP		Picture / Format		
	Position PIP		TV/Radio /		





















Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Vol+		Vol+
	Vol-		Vol-
	Mute		Mute / Dimmer
	Return		Back / Return
	PR+		CH+ / Page+
	>>I		>>I / Preset+
	I<<		I<< / Preset-
	PR-		CH- / Page-
	Exit		Exit / Cancel / Clear
	Menu		Menu / Home
	Up		Up
	Down		Down
	Right/Zoom+		Right
	Left/Zoom-		Left
	OK		OK
	Red		Red / Netflix / Search

Originalfernbedienung Ersatzfernbedienung

	Sound		Sound / Title
	List		Shift + Smart / List
	Green		Green / APP / Repeat
	Info		Info / Angle
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Mosaic		Smart / List
	Violet		Display / Media
	Text		Text / Goto
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8




Originalfernbedienung Ersatzfernbedienung

	9		9
	0/-/-		0
	AV		AV / Input / RDS
	PIP		Zoom / Size
	<</Pat-Mix		<< / Tune-
	Play/?		Play / Slow
	>>		>> / Tune+
	Rec/100		Rec / Rec Mode
	Stop		Stop / Hold
	Pause/----		Pause / Step / Freeze
	Size PIP		Picture / Format
	Position PIP		TV/Radio /

Originalfernbedienung Ersatzfernbedienung

