



































**Originalfernbedienung Ersatzfernbedienung**

	Power		Power
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Lang		Audio / Lang I/II
	Tv/Radio		TV/Radio /
	Game		D.Menu / Top
	FAV		Fav / Marker / PC
	Recall		Back / Return

**Originalfernbedienung Ersatzfernbedienung**

	Dev.List		Display / Media
	EPG		Guide / EPG / -/-
	Subtitle		Subtitle / EQ
	Text		Text / Goto
	Info		Info / Angle
	Menu		Menu / Home
	Exit		Exit / Cancel / Clear
	Zoom		Zoom / Size
	Timeshift		Setup / OPT /
	CH+		CH+ / Page+
	CH-		CH- / Page-
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		OK
	Vol+		Vol+



