




























































Originalfernbedienung Ersatzfernbedienung

Theatre		Fav / Marker / PC
One-Touch Play	 + 	Shift + Play /
Power		Power
Sleep		Sleep / Timer
Night		Text / Goto
Dynamic Bass		Eject / Surround
TV	 + 	Shift + 1
TV		TV/Radio /
1		1
2		2
3		3
4		4
5		5
6		6
7		7
8		8
9		9

Originalfernbedienung Ersatzfernbedienung

Clear		Exit / Cancel / Clear
0		0
Time	 + 	Shift + Sleep / Timer
Audio		Audio / Lang I/II
Subtitles / D.Tuning		Subtitle / EQ
Angle	 + 	Shift + Info / Angle
System Menu	 + 	Shift + Menu /
Red		Red / Netflix / Search
Green		Green / APP / Repeat
Yellow		Yellow / YouTube / Repeat
Blue		Blue / Prime Video / Random
Top Menu		D.Menu / Top
Display		Display / Media
Pop Up / Menu		Menu / Home
Up		Up
Left		Left
Enter		OK



Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
Right		Right	
Return		Back / Return	
Down		Down	
Options		Setup / OPT /	
Home		Smart / List	
Function		AV / Input / RDS	
Sound Mode		Sound / Title	
I<< / Preset-		I<< / Preset-	
<- Replay		CH- / Page-	
-> Advance		CH+ / Page+	
>>I / Preset+		>>I / Preset+	
<< / Tuning-		<< / Tune-	
Play		Play / Slow	
>> / Tuning+		>> / Tune+	
Scene Search	 + 	Shift + Red / Netflix /	
Pause		Pause / Step / Freeze	
Stop		Stop / Hold	
Mute		Mute / Dimmer	
Vol+		Vol+	
Vol-		Vol-	
Display		Info / Angle	



