


















Originalfernbedienung Ersatzfernbedienung

	Standby		Power
	OSD		Display / Media
	Menu		Menu / Home
	Open / Close		Eject / Surround
	V.Mode		Picture / Format
	1		1
	2		2
	3		3
	Subtitle		Subtitle / EQ
	4		4
	5		5
	6		6
	Title / PBC		Sound / Title
	7		7
	8		8
	9		9
	Angle		Info / Angle

Originalfernbedienung Ersatzfernbedienung

	Search		Red / Netflix / Search
	0		0
	10+		Guide / EPG / -/--
	Setup		Setup / OPT /
	Up		Up
	Zoom		Zoom / Size
	Prog		TV/Radio /
	Left		Left
	Play / Enter		OK
	Play / Enter		Play / Slow
	Right		Right
	Prev		I<< / Preset-
	F.Rev		<< / Tune-
	Down		Down
	F.Fwd		>> / Tune+
	Next		>>I / Preset+
	Stop		Stop / Hold



