





































Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|------------|---|------------------------|
|  | Standby |  | Power |
|  | Open/Close |  | Eject / Surround |
|  | Goto |  | Shift + Text / |
|  | Step |  | Shift + Pause / Step / |
|  | Prog |  | TV/Radio / |
|  | Mute |  | Mute / Dimmer |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | Audio |  | Audio / Lang I/II |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | Subtitle |  | Subtitle / EQ |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |

























Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|---------|---|---------------------------|
|  | Zoom |  | Zoom / Size |
|  | 0/10 |  | 0 |
|  | 10+ |  | Guide / EPG / -/-- |
|  | A-B |  | Yellow / YouTube / Repeat |
|  | OSD |  | Display / Media |
|  | Repeat |  | Green / APP / Repeat |
|  | Menu |  | Menu / Home |
|  | Volume+ |  | Vol+ |
|  | Angle |  | Info / Angle |
|  | Video |  | Shift + 4 |
|  | Slow |  | Shift + Play / |
|  | Volume- |  | Vol- |
|  | Setup |  | Setup / OPT / |
|  | Up |  | Up |
|  | L/R |  | Text / Goto |
|  | Left |  | Left |
|  | Enter |  | OK |





Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|---------|---|-----------------------|
|  | Right |  | Right |
|  | Play |  | Play / Slow |
|  | Pause |  | Pause / Step / Freeze |
|  | Stop |  | Stop / Hold |
|  | Down |  | Down |
|  | N/P |  | Picture / Format |
|  | Title |  | Sound / Title |
|  | DVD/USB |  | Shift + 2 |
|  | I<< |  | I<< / Preset- |
|  | >>I |  | >>I / Preset+ |
|  | << |  | << / Tune- |
|  | >> |  | >> / Tune+ |

Originalfernbedienung Ersatzfernbedienung

| | | | |
|--|--|--|--|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

