























Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Mute		Mute
	Sleep		Sleep
	P.Mode		Shift + Format
	S.Mode		Dual
	Rec		Rec
	DTV		Smart
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0

Originalfernbedienung Ersatzfernbedienung

	List / Goto		List
	Menu		Menu
	Source		AV
	Aspect		Format
	Recall		Back
	Info		Info
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	CH -		Ch -
	CH +		Ch +
	Vol -		Vol -
	Vol +		Vol +
	Audio		Shift + Dual
	FAV / Title		Pre Ch



