





Originalfernbedienung Ersatzfernbedienung

	Standby		Power
	Rec PVR		Rec
	PVR List		List
	Mute		Mute
	EPG		Guide
	Audio		Dual
	Info		Info
	TTX		Text
	Subtitle		Subt
	Menu		Menu
	Exit		Exit
	Favourite		Pre Ch
	Tv/Radio		TV/R
	CH+		Ch +
	CH-		Ch -
	Up		Up
	Down		Down

Originalfernbedienung Ersatzfernbedienung

	Right		Right
	Left		Left
	OK		Ok
	Vol+		Vol +
	Vol-		Vol -
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Recall		Back
	Goto		AV



