





































**Originalfernbedienung    Ersatzfernbedienung**

	DVD / TV / AV		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Mute		Mute
	Repeat / TV/Radio		TV/R
	Repeat / TV/Radio		Shift + Text
	Exit		Exit
	Up / CH+		Up
	Up / CH+		Ch +

**Originalfernbedienung    Ersatzfernbedienung**

	Down / CH-		Down
	Down / CH-		Ch -
	Right / Vol+		Right
	Right / Vol+		Vol +
	Left / Vol-		Left
	Left / Vol-		Vol -
	OK		Ok
	Pg Up		Shift + Ch +
	Pg Dn		Shift + Ch -
	Title		Smart
	Info		Info
	Goto / FAV		Pre Ch
	Audio		Dual
	Sub-T		Subt
	Zoom / TTX		Text
	Zoom / TTX		Eject
	Setup		Options



