
































Originalfernbedienung Ersatzfernbedienung

	Energy/Saving		Eject / Surround
	Power		Power
	TV/Rad		TV/Radio /
	Guide		Guide / EPG / -/--
	Info		Info / Angle
	Ratio		Picture / Format
	Input		AV / Input / RDS
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	List		Smart / List

Originalfernbedienung Ersatzfernbedienung

	0		0
	Q.View		Display / Media
	Settings		Menu / Home
	Up		Up
	Q.Menu		D.Menu / Top
	Left		Left
	OK		OK
	Right		Right
	Back		Back / Return
	Down		Down
	Exit		Exit / Cancel / Clear
	Vol+		Vol+
	FAV		Fav / Marker / PC
	P+		CH+ / Page+
	Vol-		Vol-
	Simplink		Sound / Title
	P-		CH- / Page-



