





































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Guide/List		Guide / EPG / -/--
	0/Quick Access		0
	.../AD/SAP		Fav / Marker / PC
	Vol+		Vol+
	CH+		CH+ / Page+
	Mute		Mute / Dimmer
	Vol-		Vol-

Originalfernbedienung Ersatzfernbedienung

	CH-		CH- / Page-
	Home		Menu / Home
	Voice		Display / Media
	Sources		AV / Input / RDS
	Up		Up
	Left		Left
	Wheel Up		>> / Preset+
	Right		Right
	Wheel Down		<< / Preset-
	OK		OK
	Down		Down
	Back		Back / Return
	*		D.Menu / Top
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random





Originalfernbedienung		Ersatzfernbedienung	
	Netflix	+	Shift + Red / Netflix /
	prime video	+	Shift + Blue / Prime
	Disney+		TV/Radio /
	Rakuten Tv		Picture / Format
	Smart Colors		Smart / List
	Alexa		Zoom / Size

