



Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Eco		3D
	CH/Page+		Ch +
	CH/Page-		Ch -
	Sleep		Sleep
	Mute		Mute
	Volume+		Vol +
	Volume-		Vol -
	Info		Info
	Option		Options
	Setup		Menu
	Back		Back
	Up		Up
	Enter		Ok
	Down		Down
	Right		Right
	Left		Left

Originalfernbedienung Ersatzfernbedienung

	Play		Play
	Pause		Pause
	Stop		Stop
	Home		Smart
	>>I/Tune+		>>I
	I<</Tune-		I<<
	>>		>>
	<<		<<
	Green/Movie		Green
	Red/Music		Red
	Blue/Game		Blue
	Yellow/Pure		Yellow
	1		1
	2		2
	3		3
	4		4
	5		5





**Originalfernbedienung    Ersatzfernbedienung**

	6		6
	7		7
	8		8
	9		9
	0		0
	Smart Select 1		Text
	Smart Select 2		AV
	Smart Select 3		Format
	TV Audio		TV/R
	Smart Select 4		D. Menu
	CBL/SAT		Shift + 1
	DVD		Shift + 2
	Blu-ray		Shift + 3
	AUX1		Shift + 4
	Tuner		Shift + 5
	Bluetooth		Shift + 6
	Game		Shift + 7

**Originalfernbedienung    Ersatzfernbedienung**

	Phono		Shift + 9
	AUX2		Shift + 8
	iPod / USB		Guide
	Internet Radio		Pre Ch
	Media Player		Shift + Guide
	CD		Shift + 0
	Online Music		Shift + Pre Ch




































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	CH/Page+		Ch +
	CH/Page-		Ch -
	Sleep		Sleep
	Mute		Mute
	Volume+		Vol +
	Volume-		Vol -
	Back		Back
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	Home		Smart
	Stop		Stop
	Pause		Pause
	Play		Play

Originalfernbedienung Ersatzfernbedienung

	>>		>>
	<<		<<
	>> /Tune+		>>
	<</Tune-		<<
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Smart Select 1		Text
	Smart Select 2		AV
	Smart Select 3		Format








































































**Originalfernbedienung Ersatzfernbedienung**

	Smart Select 4		3D
	TV Audio		TV/R
	Media Player		Shift + Guide
	Internet Radio		Pre Ch
	CBL/SAT		Shift + 1
	DVD		Shift + 2
	Blu-ray		Shift + 3
	AUX1		Shift + 4
	Tuner		Shift + 5
	Bluetooth		Shift + 6
	Game		Shift + 7
	AUX2		Shift + 8
	Phono		Shift + 9
	iPod / USB		Guide
	CD		Shift + 0
	Online Music		Shift + Pre Ch

**Originalfernbedienung Ersatzfernbedienung**






Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
 Power	 Power	 >> /Tune+	 >>
 CH/Page+	 Ch +	  <</Tune-	  <<
 CH/Page-	 Ch -	 <<	 <<
 Sleep	 Sleep	 >>	 >>
 Mute	 Mute	 1	 1
 Volume+	 Vol +	 2	 2
 Volume-	 Vol -	 3	 3
 Back	 Back	 4	 4
 Up	 Up	 5	 5
 Down	 Down	 6	 6
 Right	 Right	 7	 7
 Left	 Left	 8	 8
 Enter	 Ok	 9	 9
 Home	 Smart	 0	 0
 Stop	 Stop	 Smart Select 1	 Text
 Pause	 Pause	 Smart Select 2	 AV
 Play	 Play	 Smart Select 3	 Format





Originalfernbedienung Ersatzfernbedienung

	Smart Select 4		3D
	TV Audio		TV/R
	Media Player		Shift + Guide
	Internet Radio		Pre Ch
	CBL/SAT		Shift + 1
	DVD		Shift + 2
	Blu-ray		Shift + 3
	AUX1		Shift + 4
	Tuner		Shift + 5
	Bluetooth		Shift + 6
	Game		Shift + 7
	AUX2		Shift + 8
	Phono		Shift + 9
	iPod / USB		Guide
	CD		Shift + 0
	Online Music		Shift + Pre Ch

Originalfernbedienung Ersatzfernbedienung