
























Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|--------|---|--------|
|  | Power |  | Power |
|  | Mute |  | Mute |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | FAV |  | Pre Ch |
|  | Recall |  | Back |
|  | Menu |  | Menu |
|  | EPG |  | Guide |
|  | Info |  | Info |

Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|------------|---|-------|
|  | Exit |  | Exit |
|  | Up / CH+ |  | Up |
|  | Up / CH+ |  | Ch + |
|  | Down / CH- |  | Down |
|  | Down / CH- |  | Ch - |
|  | Right / V+ |  | Right |
|  | Right / V+ |  | Vol + |
|  | Left / V- |  | Left |
|  | Left / V- |  | Vol - |
|  | OK / Group |  | Ok |
|  | << |  | << |
|  | >> |  | >> |
|  | I<< |  | I<< |
|  | I>> |  | I>> |
|  | Filelist |  | Smart |
|  | Filelist |  | List |
|  | Rec |  | Rec |



