













































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Mute		Mute
	Source		AV
	P.Mode		3D
	S.Mode		Shift + Dual
	Audio/I-II		Dual
	P.Size		Format
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0

Originalfernbedienung Ersatzfernbedienung

	Menu		Menu
	Info		Info
	Exit		Exit
	FAV.CH		Pre Ch
	Sleep		Sleep
	Jump		Options
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Vol+		Vol +
	Vol-		Vol -
	P+		Ch +
	P-		Ch -
	Red/D.Setup		Red
	Green/Repeat		Green



