



































































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Open/Close VCR		Pre Ch
	Open/Close		Guide
	DVD/VCR		Media
	Input Select		Shift + AV
	Display		Info
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Up		Up

Originalfernbedienung Ersatzfernbedienung

	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	P+		Ch +
	P-		Ch -
	TRK+		Vol +
	TRK-		Vol -
	Setup		Options
	Cancel		Exit
	Return		Back
	Title Menu/Top		Menu
	DVD Menu		D. Menu
	One Touch		Green
	Repeat A-B		Text
	Play Mode/Repeat		Shift + Play
	Zoom		Eject



