



Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Rec		Rec / Rec Mode
	Red		Red / Netflix / Search
	I<<		I<< / Preset-
	Green/[]		Green / APP / Repeat
	Stop		Stop / Hold
	Yellow		Yellow / YouTube / Repeat
	Play/[≡]		Play / Slow
	Blue/[■]		Blue / Prime Video / Random
	>>I		>>I / Preset+
	AV/[?]		AV / Input / RDS
	I-II/[≡≡]		Audio / Lang I/II
	Picture / Format		
	Zoom / Size		
	Menu		Menu / Home
	[≡]		Text / Goto
	Pause		Pause / Step / Freeze

Originalfernbedienung Ersatzfernbedienung

	Left		Left
	Up		Up
	Right		Right
	OK		OK
	Down		Down
	Vol+		Vol+
	Mute		Mute / Dimmer
	P+		CH+ / Page+
	Vol-		Vol-
	Smart ♪		Sound / Title
	P-		CH- / Page-
	Smart []		Smart / List
	1		1
	2		2
	3		3
	4		4
	5		5




















Originalfernbedienung Ersatzfernbedienung



























		Eject / Surround
		Subtitle / EQ
		Power
		Rec / Rec Mode
		I<< / Preset-
		Red / Netflix / Search
		Green / APP / Repeat
		Stop / Hold
		Play / Slow
		Yellow / YouTube / Repeat
		>>I / Preset+
		AV / Input / RDS
		Audio / Lang I/II
		Zoom / Size
		Picture / Format
		Menu / Home
		Pause / Step / Freeze

Originalfernbedienung Ersatzfernbedienung








		Text / Goto
		Left
		Up
		Right
		OK
		Down
		Vol+
		Mute / Dimmer
		CH+ / Page+
		Vol-
		Sound / Title
		CH- / Page-
		Smart / List
		1
		2
		3
		4




Originalfernbedienung Ersatzfernbedienung

	Power		Power
	-0-		Subtitle / EQ
	I<<		I<< / Preset-
	>>I		>>I / Preset+
	AV/[?]		AV / Input / RDS
	I-II/[≡ ≡]		Audio / Lang I/II
	[<>]/[+]		Zoom / Size
	Pause		Pause / Step / Freeze
	[≡]		Text / Goto
	Left		Left
	Up		Up
	Right		Right
	OK		OK
	Down		Down
	Vol+		Vol+
	Mute		Mute / Dimmer
	P+		CH+ / Page+

Originalfernbedienung Ersatzfernbedienung

	Vol-		Vol-
	Smart J		Sound / Title
	P-		CH- / Page-
	Smart []		Smart / List
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	P<P		Fav / Marker / PC

