







































































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Ambilight		3D
	Source		AV
	Settings		Options
	Top Picks		D. Menu
	Search		TV/R
	TV/Exit		Exit
	Tv Guide		Guide
	Windows		Info
	List		List
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	←		Back
	+		Format

Originalfernbedienung Ersatzfernbedienung

	△		Smart
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Netflix		Media
	≡+		Ch +
	≡-		Ch -
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6



