








































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Stop		Stop / Hold
	Pause		Pause / Step / Freeze
	Rec		Rec / Rec Mode
	<<		<< / Tune-
	Play		Play / Slow
	>>		>> / Tune+
	USB		Shift + 8
	Search		Shift + Green / APP / Repeat
	*/Settings		Setup / OPT /
	Tv Guide		Guide / EPG / -/--
	List		Shift + Smart / List
	Sources		AV / Input / RDS
	Smart Tv		Smart / List
	Home		Menu / Home
	Exit/TV		Exit / Cancel / Clear
	Red		Red / Netflix / Search

Originalfernbedienung Ersatzfernbedienung

	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	i		Info / Angle
	Up		Up
	Options		Shift + Setup / OPT / Tools
	Left		Left
	OK		OK
	Right		Right
	Back		Back / Return
	Down		Down
	[<>]		Picture / Format
	Vol+		Vol+
	Netflix		Shift + Red / Netflix /
	CH+		CH+ / Page+
	Vol-		Vol-
	Mute		Mute / Dimmer





Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
	CH-		CH- / Page-
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Subtitle		Subtitle / EQ
	0		0
	Text		Text / Goto

