







































































Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|---------|---|--------|
|  | Power |  | Power |
|  | Source |  | AV |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | TTX/MIX |  | Text |
|  | PRE-CH |  | Pre Ch |
|  | Mute |  | Mute |
|  | CH-List |  | Guide |
|  | Vol+ |  | Vol + |

Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|---------|---|---------|
|  | Vol- |  | Vol - |
|  | P+ |  | Ch + |
|  | P- |  | Ch - |
|  | Tools |  | Options |
|  | Media.P |  | Media |
|  | Ball |  | Smart |
|  | Info |  | Info |
|  | Exit |  | Exit |
|  | Return |  | Back |
|  | Menu |  | Menu |
|  | Enter |  | Ok |
|  | Up |  | Up |
|  | Down |  | Down |
|  | Left |  | Left |
|  | Right |  | Right |
|  | Red |  | Red |
|  | Green |  | Green |





Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|----------|---|---------|
|  | Yellow |  | Yellow |
|  | Blue |  | Blue |
|  | E-Manual |  | D. Menu |
|  | Sleep |  | Sleep |
|  | Micro |  | Dual |
|  | Stop |  | Stop |
|  | <</ << |  | << |
|  | Play |  | Play |
|  | Pause |  | Pause |
|  | >>/>> |  | >> |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

Originalfernbedienung Ersatzfernbedienung

| | |
|--|--|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

