







Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Open/Close		Eject
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Step		Format
	3D		3D
	S.Fit		List
	Zoom		Shift + Eject
	Digest		TV/R

Originalfernbedienung Ersatzfernbedienung

	<<		<<
	>>		>>
	l<<		l<<
	>>l		>>l
	Stop		Stop
	Play		Play
	Pause		Pause
	Top Menu		Shift + Menu
	Menu		Menu
	Return		Back
	Display		Info
	Clear		Exit
	Mode		AV
	Up		Up
	Down		Down
	Right		Right
	Left		Left



