












































Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
On/Off		Power	
Mute		Mute	
Update		Smart	
Reveal		List	
Info		Info	
Subt.List		Subt	
Sleep Timer		Sleep	
Txt Stop		Stop	
Return TV		TV/R	
Menu video		D. Menu	
Text		Text	
Txt Expand		Eject	
TV/AV		AV	
Menu		Menu	
Menu Up		Up	
Display		Shift + Info	
Menu Left		Left	
OK Enter		Ok	
Menu Right		Right	
Menu Off		Exit	
Menu Down		Down	
Back		Back	
Volume+		Vol +	
Chan.Up		Ch +	
Volume-		Vol -	
Menu audio		Dual	
Chan.Down		Ch -	
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	



Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
8		8	
9		9	
Guide -/-- 1.		Guide	
0/10		0	
2.Fav P/C 2.		Pre Ch	
Red		Red	
Green		Green	
Yellow		Yellow	
Browse		Media	
Blue		Blue	
Tone+		>>I	
Tone-		I<<<	
Audio-		<<<	
Audio+		>>>	
Contrast+		Shift + Ch +	
Contrast-		Shift + Ch -	
Surround		Shift + Red	
Nicam/Mono		Shift + Green	
Level L		Shift + Yellow	
Level R/Woofer		Shift + Blue	

