



Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Mute		Mute
	USB		1
	BT		2
	AUX		3
	OPT		5
	Line In		6
	Vol+		Vol +
	Vol+		Up
	Vol-		Vol -
	Vol-		Down
	>>		>>
	>>		Right
	<<		<<
	<<		Left
	Play / Pause		Ok
	Play / Pause		Play

Originalfernbedienung Ersatzfernbedienung

	Play / Pause		Pause

