






































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Mute		Mute
	(?)		3D
	*		D. Menu
	Input		AV
	♥		Shift + Pre Ch
	( ↑ )		Format
	(i)		Info
	Recall		Pre Ch
	Zoom+		Ch +
	Zoom-		Ch -
	(:)		Text
	Vol+		Vol +
	Vol-		Vol -
	(::)		Guide
	Windows		Media
	World		Options

Originalfernbedienung Ersatzfernbedienung

	Menu		Menu
	Home		Smart
	Back		Back
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Stop		Stop
	Play		Play
	Pause		Pause
	Search		TV/R
	<<		<<
	>>		>>
	I<<		I<<
	>>I		>>I
	Red		Red



