




























































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Mute		Mute / Dimmer
	Preset -		I<< / Preset-
	Preset +		>>I / Preset+
	Stereo		Audio / Lang I/II
	Sleep		Sleep / Timer
	Level		D.Menu / Top
	Test		Text / Goto
	Set Menu		Menu / Home
	Up		Up
	Multi CH In		OK
	Down		Down
	Volume +		Vol+
	Prog +		CH+ / Page+
	Vollume -		Vol-
	Prog -		CH- / Page-
	DVD		2

Originalfernbedienung Ersatzfernbedienung

	CD		3
	VCR		4
	Tuner		6
	V-AUX		7
	MD / CD-R		8
	DTV / CBL		9
	A / B / C / D / E		Yellow / YouTube / Repeat
	Dolby / DTS		Shift + Audio / Lang I/II
	Night		Shift + Sleep / Timer
	+		Shift + Up
	-		Shift + Down
	6.1 / 5.1		Shift + 6

