






































Originalfernbedienung Ersatzfernbedienung









	Power Receiver		Power
	Sleep		Sleep
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Return		Back
	Enter		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Setup		Menu
	Option		Options
	BD/DVD		Red
	TV		Green
	CD		Yellow
	Radio		Blue

Originalfernbedienung Ersatzfernbedienung

	Audio 1		1
	Audio 2		2
	Audio 3		3
	Audio 4		4
	Audio 5		5
	Audio 6		6
	HDMI 1		7
	HDMI 2		8
	HDMI 3		9
	Tuner Tuner		Guide
	Memory Tuner		Pre Ch
	Preset Up Tuner		Ch +
	Preset Down		Ch -
	Tuning Up		>>
	Tuning Down		<<
	Info		Info
	Movie Sound		Subt





Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
 Music Sound	 Dual		
 Stereo/Enhancer Sound	 Format		
 Straight Sound	 AV		
 Sur. Decode	 3D		

