







































































Original	Replacement	Original	Replacement
 Power	 Power	 Favorite	 Shift + Pre Ch
 Mute	 Mute	 Play	 Play
 Subtitle	 Subt	 Pause	 Pause
 <<	 <<	 Stop	 Stop
 >>	 >>	 Info	 Info
 I<<	 I<<	 1	 1
 >>I	 >>I	 2	 2
 Record	 Rec	 3	 3
 Up	 Up	 4	 4
 CH+	 Ch +	 5	 5
 CH-	 Ch -	 6	 6
 Down	 Down	 7	 7
 Right	 Right	 8	 8
 Vol+	 Vol +	 9	 9
 Vol-	 Vol -	 0	 0
 Left	 Left	 EPG	 Guide
 OK	 Ok	 Tv/Radio	 TV/R





Original	Replacement
 Audio	 Dual
 Recall	 Pre Ch
 Repeat	 +  Shift + Text
 Teletext	 Text
 File	 Smart
 Device	 AV
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Menu	 Menu
 Exit	 Exit

Original	Replacement

