







































































Original	Replacement	Original	Replacement
 Standby	 Power	 Down	 Down
 PVR Rec	 Rec	 Right	 Right
 PVR List	 List	 Left	 Left
 Mute	 Mute	 OK	 Ok
 EPG	 Guide	 Vol+	 Vol +
 Audio	 Dual	 Vol-	 Vol -
 Info	 Info	 1	 1
 DTV/VCR	 Smart	 2	 2
 TTX	 Text	 3	 3
 Subtitle	 Subt	 4	 4
 Menu	 Menu	 5	 5
 Exit	 Exit	 6	 6
 Tv/Radio	 TV/R	 7	 7
 Favourite	 Pre Ch	 8	 8
 CH+	 Ch +	 9	 9
 CH-	 Ch -	 0	 0
 Up	 Up	 Recall	 Back

























































Original		Replacement		Original		Replacement	
	Goto		3D				
	<<		<<				
	>>		>>				
	1<<		1<<				
	>>1		>>1				
	Play		Play				
	Pause		Pause				
	Stop		Stop				
	RPT		Media				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				





	Original	Replacement		Original	Replacement
	Standby		Power		Down
	PVR Rec		Rec		Right
	PVR List		List		Left
	Mute		Mute		Ok
	EPG		Guide		Vol +
	Audio		Dual		Vol -
	Info		Info		1
	DTV/VCR		Smart		2
	TTX		Text		3
	Subtitle		Subt		4
	Menu		Menu		5
	Exit		Exit		6
	Tv/Radio		TV/R		7
	Favourite		Pre Ch		8
	CH+		Ch +		9
	CH-		Ch -		0
	Up		Up		Recall
					Back





Original	Replacement	Original	Replacement
 GOTO	 3D		
			
			
			
			
			
			
			
			
			
			
			
			

