







































































Original	Replacement	Original	Replacement
 Standby/On	 Power	 Pause/PTY Seek	 Pause / Step / Freeze
 1	 1	 Random/PTY Seek Start	 Blue / Prime Video / Random
 2	 2	 I<</Preset	 I<< / Preset-
 3	 3	 Play	 Play / Slow
 4	 4	 >>I/Preset Up	 >>I / Preset+
 5	 5	 GUI	 Smart / List
 6	 6	 Up	 Up
 7	 7	 Menu	 Menu / Home
 8	 8	 Left	 Left
 9	 9	 Enter	 OK
 0	 0	 Right	 Right
 Dimmer	 Shift + Mute / Dimmer	 Set Up	 Setup / OPT /
 Sleep	 Sleep / Timer	 Down	 Down
 Repeat	 Green / APP / Repeat	 Top	 Back / Return
 A-B	 Yellow / YouTube / Repeat	 Top	 D.Menu / Top
 Stop	 Stop / Hold	 Mute	 Mute / Dimmer
 Prog/Freq/Text	 TV/Radio /	 Volume+	 Vol+

Original	Replacement	Original	Replacement
 Pause/PTY Seek	 Pause / Step / Freeze	 Random/PTY Seek Start	 Blue / Prime Video / Random
 I<</Preset	 I<< / Preset-	 Play	 Play / Slow
 >>I/Preset Up	 >>I / Preset+	 GUI	 Smart / List
 Up	 Up	 Menu	 Menu / Home
 Left	 Left	 Enter	 OK
 Right	 Right	 Set Up	 Setup / OPT /
 Down	 Down	 Top	 Back / Return
 Top	 D.Menu / Top	 Mute	 Mute / Dimmer
 Volume+	 Vol+		












Original	Replacement
Power Tv	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
TV CH+	CH+ / Page+
TV CH-	CH- / Page-
TV Input	AV / Input / RDS
TV Vol+	Vol+
TV Vol-	Vol-
TV	Shift + 1

Original	Replacement
DVD/CD	Shift + 3
DVD/CD	Shift + 2
AUX	Shift + 7
Tuner	Shift + 6





Original	Replacement
 Standby/On	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Prog/Freq/Text	 TV/Radio /
 Pause/PTY Seek	 Pause / Step / Freeze
 Random/PTY Seek Start	 Play / Slow
 I<</Preset	 I<< / Preset-
 >>I/Preset Up	 >>I / Preset+
 Mute	 Mute / Dimmer

Original	Replacement
 Volume+	 Vol+
 Volume-	 Vol-
 TV	 Shift + 1
 DVD/CD	 Shift + 3
 DVD/CD	 Shift + 2
 AUX	 Shift + 7
 Tuner	 Shift + 6



