







































Original	Replacement
 Power	 Power
 Source Search	 Source
 Enter	 Enter
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Menu	 Menu
 ESC	 Shift + Menu
 Vol+	 Page  Vol
 Vol-	 Page  Vol
 Help	 Info/Help
 Freeze	 Timer/Freeze
 A/V Mute	 Blank/Mute
 Auto	 Auto
 User	 Shift + Mode
 Aspect	 Eco/Aspect

Original	Replacement
 E-Zoom+	 Play + / Play
 Pointer	 Shift + Auto
 E-Zoom-	 Stop - / Stop
 Color Mode	 Mode
 Page Up	 Shift + Up
 Page Down	 Shift + Down
 USB	 Focus/Volt
 Computer	 Video/Comp
 Video	 Shift + Video/Comp
 LAN	 Invert/3D
 1	 Shift + Page  Vol
 2	 Shift + Play + / Play
 3	 Shift + Focus/Volt
 4	 Shift + Page  Vol
 5	 Shift + - / Stop
 6	 Shift + Info/Help
 7	 Shift + Eco/Aspect



