



















Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	Play / Pause		Play
	USB / Stop		Stop
	USB / Stop		Media
	Sleep		Rec
	Info		Info
	Red / I<<		Red
	Red / I<<		I<<
	Green / >>I		>>I
	Green / >>I		Green
	Yellow / <<		Yellow
	Yellow / <<		<<
	Blue / >>		Blue
	Blue / >>		>>
	FAV		Pre Ch
	SAT		AV
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	Menu		Menu
	Exit		Exit
	Subtitle		Subt
	TXT		Text
	Recall		Back
	Audio		Dual
	Page +		Ch +
	Page -		Ch -
	1		1
	2		2
	3		3
	4		4





Original		Replacement		Original		Replacement	
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
	0		0				
	EPG		Guide				
	TV / Radio		TV/R				

