































| Original | Replacement | Original | Replacement |
|----------|----------------|----------|----------------------|
| | Power | | Power |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | 0 | | 0 |
| | AV/CL | | AV / Input / RDS |
| | Zoom | | Zoom / Size |
| | [...]/Subtitle | | Subtitle / EQ |
| | Audio/Language | | Audio / Lang I/II |
| | ◀/Camera | | Shift + Info / Angle |
| | ? | | Setup / OPT / |
| | ECO | | Display / Media |
| | CEC | | Smart / List |
| | Mute | | Mute / Dimmer |
| | i | | Info / Angle |
| | Z/Back | | Back / Return |
| | PR+ | | CH+ / Page+ |
| | Up | | Up |
| | Vol- | | Vol- |
| | Left | | Left |
| | OK | | OK |
| | Right | | Right |
| | Vol+ | | Vol+ |
| | Down | | Down |
| | PR- | | CH- / Page- |
| | TVG/Top Menu | | Guide / EPG / -/-- |
| | TVG/Top Menu | | D.Menu / Top |
| | TXT/Menu | | Text / Goto |





| Original | Replacement | Original | Replacement |
|--|---|----------|-------------|
|  TXT/Menu |  Menu / Home | | |
|  Red |  Red / Netflix / Search | | |
|  Green |  Green / APP / Repeat | | |
|  Yellow |  Yellow / YouTube / Repeat | | |
|  Blue |  Blue / Prime Video / Random | | |
|  [<>] |  Shift + Zoom / | | |
|  Rec/l> |  Rec / Rec Mode | | |
|  Play |  Play / Slow | | |
|  Pause |  Pause / Step / Freeze | | |
|  Stop |  Stop / Hold | | |
|  l< |  l<< / Preset- | | |
|  >l |  >>l / Preset+ | | |
|  << |  << / Tune- | | |
|  >> |  >> / Tune+ | | |
| | | | |
| | | | |
| | | | |





| Original | Replacement |
|----------|----------------------|
| | Power |
| | 1 |
| | 2 |
| | 3 |
| | 4 |
| | 5 |
| | 6 |
| | 7 |
| | 8 |
| | 9 |
| | 0 |
| | AV / Input / RDS |
| | Zoom / Size |
| | Subtitle / EQ |
| | Audio / Lang I/II |
| | Shift + Info / Angle |
| | Setup / OPT / |

| Original | Replacement |
|----------|--------------------|
| | Display / Media |
| | Smart / List |
| | Mute / Dimmer |
| | Info / Angle |
| | Back / Return |
| | CH+ / Page+ |
| | Up |
| | Vol- |
| | Left |
| | OK |
| | Right |
| | Vol+ |
| | Down |
| | CH- / Page- |
| | Guide / EPG / -/-- |
| | D.Menu / Top |
| | Menu / Home |









































































| Original | Replacement | Original | Replacement |
|----------|-------------|----------|-----------------------------|
| | TXT/Menu | | Text / Goto |
| | Red | | Red / Netflix / Search |
| | Green | | Green / APP / Repeat |
| | Yellow | | Yellow / YouTube / Repeat |
| | Blue | | Blue / Prime Video / Random |
| | [<>] | | Shift + Zoom / |
| | Rec/l> | | Rec / Rec Mode |
| | Play | | Play / Slow |
| | Pause | | Pause / Step / Freeze |
| | Stop | | Stop / Hold |
| | I< | | I<< / Preset- |
| | >I | | >>I / Preset+ |
| | << | | << / Tune- |
| | >> | | >> / Tune+ |
| | | | |
| | | | |
| | | | |
| | | | |





| Original | Replacement | Original | Replacement |
|---|----------------|---|----------------------|
|  | Power |  | Power |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | AV/CL |  | AV / Input / RDS |
|  | Zoom |  | Zoom / Size |
|  | [...]/Subtitle |  | Subtitle / EQ |
|  | Audio/Language |  | Audio / Lang I/II |
|  | ◀/Camera |  | Shift + Info / Angle |
|  | ? |  | Setup / OPT / |
|  | ECO |  | Display / Media |
|  | CEC |  | Smart / List |
|  | Mute |  | Mute / Dimmer |
|  | i |  | Info / Angle |
|  | Z/Back |  | Back / Return |
|  | PR+ |  | CH+ / Page+ |
|  | Up |  | Up |
|  | Vol- |  | Vol- |
|  | Left |  | Left |
|  | OK |  | OK |
|  | Right |  | Right |
|  | Vol+ |  | Vol+ |
|  | Down |  | Down |
|  | PR- |  | CH- / Page- |
|  | TVG/Top Menu |  | Guide / EPG / -/-- |
|  | TVG/Top Menu |  | D.Menu / Top |
|  | TXT/Menu |  | Text / Goto |









































































| Original | Replacement | Original | Replacement |
|----------|-------------|----------|-----------------------------|
| | TXT/Menu | | Menu / Home |
| | Red | | Red / Netflix / Search |
| | Green | | Green / APP / Repeat |
| | Yellow | | Yellow / YouTube / Repeat |
| | Blue | | Blue / Prime Video / Random |
| | [<>] | | Shift + Zoom / |
| | Rec/l> | | Rec / Rec Mode |
| | Play | | Play / Slow |
| | Pause | | Pause / Step / Freeze |
| | Stop | | Stop / Hold |
| | I< | | I<< / Preset- |
| | >I | | >>I / Preset+ |
| | << | | << / Tune- |
| | >> | | >> / Tune+ |
| | | | |
| | | | |
| | | | |





| Original | Replacement | Original | Replacement |
|---|----------------|---|----------------------|
|  | Power |  | Power |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | AV/CL |  | AV / Input / RDS |
|  | Zoom |  | Zoom / Size |
|  | [...]/Subtitle |  | Subtitle / EQ |
|  | Audio/Language |  | Audio / Lang I/II |
|  | ◀/Camera |  | Shift + Info / Angle |
|  | ? |  | Setup / OPT / |
|  | ECO |  | Display / Media |
|  | CEC |  | Smart / List |
|  | Mute |  | Mute / Dimmer |
|  | i |  | Info / Angle |
|  | Z/Back |  | Back / Return |
|  | PR+ |  | CH+ / Page+ |
|  | Up |  | Up |
|  | Vol- |  | Vol- |
|  | Left |  | Left |
|  | OK |  | OK |
|  | Right |  | Right |
|  | Vol+ |  | Vol+ |
|  | Down |  | Down |
|  | PR- |  | CH- / Page- |
|  | TVG/Top Menu |  | Guide / EPG / -/-- |
|  | TVG/Top Menu |  | D.Menu / Top |
|  | TXT/Menu |  | Text / Goto |





| Original | Replacement | Original | Replacement |
|----------|-------------|----------|-----------------------------|
| | TXT/Menu | | Menu / Home |
| | Red | | Red / Netflix / Search |
| | Green | | Green / APP / Repeat |
| | Yellow | | Yellow / YouTube / Repeat |
| | Blue | | Blue / Prime Video / Random |
| | [<>] | | Shift + Zoom / |
| | Rec/l> | | Rec / Rec Mode |
| | Play | | Play / Slow |
| | Pause | | Pause / Step / Freeze |
| | Stop | | Stop / Hold |
| | I< | | I<< / Preset- |
| | >I | | >>I / Preset+ |
| | << | | << / Tune- |
| | >> | | >> / Tune+ |
| | | | |
| | | | |
| | | | |
| | | | |

