







































































Original	Replacement	Original	Replacement
 Power	 Power	 0	 0
 Mute	 Mute / Dimmer	 +10	 Guide / EPG / -/-
 L/R/ST	 D.Menu / Top	 Clear	 Exit / Cancel / Clear
 Open / Close	 Eject / Surround	 Menu	 Menu / Home
 NTSC / PAL	 Picture / Format	 Up	 Up
 1	 1	 Search	 Red / Netflix / Search
 2	 2	 Left	 Left
 3	 3	 Enter	 OK
 Angle	 Info / Angle	 Right	 Right
 4	 4	 Set Up	 Setup / OPT /
 5	 5	 Down	 Down
 6	 6	 Play	 Play / Slow
 Audio	 Audio / Lang I/II	 Title	 Sound / Title
 7	 7	 Pause	 Pause / Step / Freeze
 8	 8	 Stop	 Stop / Hold
 9	 9	 PBC	 Smart / List
 Subtitle	 Subtitle / EQ	 Return	 Back / Return



