



























Original	Replacement
 Power	 Power
 Mute	 Mute
 Display	 Info
 QV	 Options
 Picture	 Shift + Format
 Sound	 Shift + Dual
 Source	 AV
 EPG	 Guide
 FAV +	 >>
 FAV -	 <<
 FAV	 Pre Ch
 Menu	 Menu
 Size	 Format
 I/II / Top	 Dual
 Exit	 Exit
 Vol -	 Vol -
 Vol +	 Vol +

Original	Replacement
 Up	 Up
 Left	 Left
 Enter	 Ok
 Right	 Right
 Down	 Down
 CH -	 Ch -
 CH +	 Ch +
 Red / USB Left	 Red
 Red / USB Left	 Shift + Left
 Green / USB	 Green
 Green / USB	 Shift + Down
 Yellow / USB Up	 Yellow
 Yellow / USB Up	 Shift + Up
 Blue / USB Right	 Blue
 Blue / USB Right	 Shift + Right
 1	 1
 2	 2







































Original		Replacement		Original		Replacement	
	3		3		SUBTL		Subt
	4		4		Prog / Mix		Smart
	5		5		Prog / Mix		Shift + Sleep
	6		6		Return / SUBPG		Back
	7		7		Repeat / Reveal		Shift + Text
	8		8		Search / Hold		TV/R
	9		9				
	0		0				
	Sleep		Sleep				
	10+		Shift + Guide				
	USB/CR / Text		Media				
	USB/CR / Text		Text				
	Play/Pause / Index		Play				
	Play/Pause / Index		Shift + Info				
	Play/Pause / Index		Pause				
	Stop / Cancel		Stop				
	Stop / Cancel		Shift + Exit				





Original	Replacement	Original	Replacement
	 Power		 9
	 AV		 0
	 Exit		 Guide
	 Menu		 Up
	 Dual		 Right
	 Media		 Ok
	 Options		 Left
	 Text		 Down
	 TV/R		 Subt
	 1		 Pause
	 2		 Rec
	 3		 <<
	 6		 Play
	 5		 >>
	 4		 Shift + Media
	 7		 Shift + Dual
	 8		 Shift + 6

