







































































Original	Replacement	Original	Replacement
	Power		Power
	Source		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	TV		TV/R
	Recall		Pre Ch
	Mute		Mute
	Internet		Smart
	Vol+		Vol +
	Vol-		Vol -
	P+		Ch +
	P-		Ch -
	Menu		Menu
	Q.Menu		D. Menu
	Back		Back
	Exit		Exit
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	i/Info		Info
	Music/Photo/Phot		Options
	Guide		Guide
	[≡]/Text		Text
	*/O		Format





	Original	Replacement	Original	Replacement
	* / Q	 3D		
	Red	 A		
	Green	 B		
	Yellow	 C		
	Blue	 D		
	Lang	 DUAL		
	[≡]..	 SUBT		
	Rec			
	[-o-]			
	Play			
	Stop			
	Pause			
	<<			
	>>			

